

## Bulk Supply Station Ink Line Priming

After attaching the ink tubes to the all of the out ports of the Bulk Supply Station and attaching the female no-drip fitting to the other end of the tubing, you will need to prime each individual ink line. If you have a 4 port BSS you'll need to prime 4 lines, a 6 port system will require all 6 lines of tubing to be primed and you will need to prime 8 ink lines on an 8 port BSS.

Priming these lines is very simple. Find the priming piece (pictured).



And plug it into each out-port line (pictured).



Then allow at least 5 mL of ink to run through the priming piece into a waste container.



Disconnect the priming piece and that specific out-port line has been primed. Repeat this process until each of the out-port lines on the Bulk Supply Station have been primed. You are then ready to attach the lines to the IM1 cartridges (while the cartridges are in their specific print stall), as pictured below.

